

PRODUCT INFORMATION



VALVE-MEDIC

CODE	M37-12
PAGE	1 of 1
DATE	March, 97

FUNCTION AND APPLICATION: A scientific blend of solvents compounded to free up noisy valve lifters by dissolving varnish and gum deposits resulting from city traffic and short trips.

OUTSTANDING PROPERTIES: One or two containers of VALVE_MEDIC® added to crankcase oil will generally free-up sticking valves and/or valve lifters. Product is quick acting, providing answer to troubled vehicle owners quickly. Easy to use. No tools or mechanical knowledge is required.

USE DIRECTIONS: Run engine to its normal operating temperature. Cut off engine. Pour VALVE-MEDIC® into crankcase and restart engine. The VALVE-MEDIC® will usually quiet the engine in 5 to 10 minutes of driving. For stubborn cars, use two containers. If trouble persists, mechanical repair is indicated.

PRODUCT LIMITATIONS: VALVE-MEDIC® will not fix worn or damaged parts. If oil is neglected or crankcase anti-pollution system ventilation is defective, noise will probably return.

PRECAUTIONS: Contains Aliphatic Petroleum Distillate (CAS# 68476-34-6) and Naphthenic Petroleum Oil Mixture (CAS# 64742-53-6/64742-52-5). Combustible. Harmful or Fatal if Swallowed. Eye and Skin Irritant. Vapors Harmful. **FIRST AID:** If Swallowed, DO NOT INDUCE VOMITING. DO NOT ADMINISTER EPINEPHRINE OR ADRENALIN! Get medical attention immediately. If eye contacted, flush with water for at least 15 minutes. Call a physician. If skin is contacted, wash thoroughly with soap and water. In case of inhalation, remove to fresh air. If adverse effects persist, consult a physician.

STORAGE & HANDLING: Store in a cool place, below 120°F away from ignition sources, oxidizing agents and acids. Keep out of reach of children.

DISPOSAL: Dispose of container, residue and excess product in accordance with all federal, state and local laws and regulations.

CONTAINER DESCRIPTION: Packaged in 12 fl oz E-Z Pour plastic bottle.

Radiator Specialty Company

P.O. BOX 34689 / CHARLOTTE, N.C. 28234 / TELEPHONE 704-377-6555

NOTICE: WHILE THIS INFORMATION IS PRESENTED IN GOOD FAITH AND BELIEVED TO BE ACCURATE, RADIATOR SPECIALTY COMPANY DOES NOT GUARANTEE SATISFACTORY RESULTS FROM RELIANCE THEREON. THE DATA IS OFFERED SOLELY FOR YOUR INFORMATION AND RADIATOR SPECIALTY COMPANY DISCLAIMS ALL LIABILITY FOR ANY LOSS OR DAMAGE FROM ITS USE. THOROUGHLY TEST ANY APPLICATION ACCORDING TO THE PRODUCT DIRECTIONS AND INDEPENDENTLY CONCLUDE SATISFACTORY PERFORMANCE. NOTHING CONTAINED HEREIN IS TO BE CONSTRUED AS A RECOMMENDATION TO USE THE PRODUCT IN VIOLATION OF ANY PATENT.